


Betätigungsarm




◀ **Nr. 12 000**

Bestellbeispiel

12000.2395-3

Nr.	Eingangsvierkant	<L>	 g
2395-3	14 x 18	500	750


Offene Ringratsche



◀ **Nr. 12 000**

Bestellbeispiel

12000.2373/11

Nr.	Eingangs- vierkant	SW	<L>	 g
2373/11	14 x 18	17	76	330
2373/12	14 x 18	18	76	330
2373/13	14 x 18	19	76	330
2373/14	14 x 18	20	76	330
2373/15	14 x 18	21	76	330
2373/16	14 x 18	22	76	330
2373/24	14 x 18	24	76	330

Einsteck- umschalratsche




◀ **Nr. 12 000**

Bestellbeispiel

12000.2376/3

Nr.	Eingangs- vierkant	Ausgangs- vierkant	 g
2376/3	14 x 18	12,5 (1/2")	278
2376/4	14 x 18	20 (3/4")	660

Einsteckvierkant



◀ **Nr. 12 000**

Bestellbeispiel

12000.2378/3

Nr.	Eingangs- vierkant	Ausgangs- vierkant	 g
2378/3	14 x 18	12,5 (1/2")	200
2378/4	14 x 18	20 (3/4")	390